

6BX/ZX/VIA86/VIA86P

User's Manual Version 1.4

The information presented in this publication has been made carefully for reliability; however, no responsibility is assumed for inaccuracies. Specifications are subject to change without notice.

IBM, PC/AT, and PC/XT are trademarks of International Business Machines Corporation.

Pentium is a trademark of Intel Corporation

AWARD is a registered trademark of Award Software Inc.

MS-MOS and WINDOWS NT are registered trademarks of Microsoft Corporation.

Trademarks and/or registered trademarks are the properties of their respective owners.

Table of Contents

Chapter 1	Introduction	1
	How this manual is organized	1
	Package checklist	2
Chapter 2	Features	3
	Features of the mainboard	3
	The mainboard layout	6
Chapter 3	Installation	7
	System Installation Setups	9
	Static Electricity Precaution	9
	Jumper Settings	10
	System Memory (DIMM moduleS)	14
	DIMM Memory Installation	15
	Wake Up On LAN	16
	Central Processing Unit (CPU)	17
	Removing the Processor	20
	Installing OEM Processor	21
	Clearance Requirements	23
	Fan Exhaust	23
	External Connectors	24